



TJERNLUND PRODUCTS, INC.

1601 Ninth Street • White Bear Lake, MN 55110-6794
PHONE (800) 255-4208 • (651) 426-2993 • FAX (651) 426-9547
Visit our web site • www.tjernlund.com



AIRESHARE™ ROOM-TO-ROOM TRANSFER FAN MODEL AS2

READ OWNERS INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION. THESE INSTRUCTIONS MUST REMAIN WITH EQUIPMENT. DO NOT DESTROY.



DESCRIPTION

The Tjernlund AireShare™ Room-to-Room Transfer fans distribute air from one conditioned space to another. Virtually every home has a room that is uncomfortably hot or cold from which some of that room's air can be shared with an adjacent room, making the temperature of both rooms more comfortable. The AireShare™ transfers air through the wall cavity created between two wall studs. The AireShare's unique option of moving the air up or down within the wall cavity allows for optimum heat transfer between rooms. In addition, locating the Grille and Diffuser, one high the other low, prevents the transfer of light and sound between these adjacent rooms.

AS2 SPECIFICATIONS & COMPONENTS

Blower:	3 Speed: 110 CFM, 95 CFM, 80 CFM (Wire for desired speed upon install)		
Motor:	120 Volts ~ 60 Hz 0.50 amps maximum, Watts (30 High, 21 Med, 16 Low)		
Impeller:	Dual Inlet, Low RPM		
Dimensions:	Diffuser:	3" x 15 1/8" (flush)	Diffuser Rough Opening: 1 1/4" High x 13 5/8" Wide
	Blower Grille:	16" x 10" x 2 1/2"	Blower Rough Opening: 7 1/4" High x 14 1/2" Wide
	Color:	Neutral White	

GENERAL INFORMATION

Every Tjernlund AireShare™ Room-to-Room Transfer fan is electrically factory line tested before shipment.

After opening carton, inspect thoroughly for shipping damage. Impeller should rotate freely and all electrical wires and connections should be secured. If any damage is found, notify freight carrier and your distributor immediately and file a concealed damage claim.

SPEED SELECTION ADVICE

Since it is impractical to calculate heating and cooling loads for the variety of geographic areas, construction methods and the temperature of transferred air we base our model selection advice on providing a minimum of 3 Air Changes/Hour (ACH) to the target room. Door under-cuts or pressure relief transfer grilles in the target room are necessary for proper AireShare performance.

(AireShare CFM x 60) / (L x W x H of target room) = ACH **NOTE:** Airesshare CFM is 110 on High, 95 on Med and 80 on Low

3-4 Air Changes/hour (ACH) recommended for best temperature equalization.

4-5 Air Changes/hour (ACH) recommended for rooms with high cooling or heating loads. Examples include rooms with extensive outside walls, windows, over tuck under garages or in extreme climates. More than one AireShare transfer fan can be installed to reach desired number of air changes for large spaces.

INSTALLATION RESTRICTIONS

The AireShare™ Transfer fan must be installed by a qualified installer in accordance with these instructions and all local codes or in their absence in accordance with the latest editions of the International Residential Code and International Electrical Code. Improper installation can create a hazardous condition such as fire, electric shock or personal injury. To reduce these risks significantly, use this device only in the manner intended by the manufacturer. If you have questions about proper usage of this device, call Tjernlund.

Always disconnect the AireShare™ Transfer fan from its power source before installation and servicing.

IMPORTANT: An in depth investigation of the wall layout is required prior to installation. Avoid a stud wall section that is a path for plumbing supply lines, drains and vents. Avoid a stud wall section that is insulated or being used as a return air duct for a forced air system. If stud walls are constructed with metal studs, order Tjernlund Model DK2 Duct Kit or seal all metal stud openings.

! WARNING

- The AireShare™ may not be used to exhaust hazardous or explosive materials or vapors.
- The AireShare™ may not be installed in a ceiling.
- The AireShare™ may not be installed in an outside wall.
- The AireShare™ may not be installed in a wall rated as a “fire wall.”
- The AireShare™ may not be used to move air from one floor (story) to another floor.
- The AireShare™ may not be used to move moisture-laden air from sources such as bathrooms and kitchens.
- The AireShare™ may not be used in a window.

WARNING: To reduce the risk of fire, electrical shock and injury to persons, the AireShare™ must be installed with the Diffuser that was provided. Do not use this product with any Diffuser other than the AS2 Diffuser.

WARNING: To reduce the risk of fire or electrical shock, do not use this fan with any solid state speed control devices.



! WARNING

Disrupt power at circuit breaker to outlets and switches within the stud wall you will be working.

BEFORE YOU START:

Determine the stud wall section that you want to use to mount the Blower and Diffuser. It may be preferable to select a stud wall section that contains an electrical outlet for wiring. **IMPORTANT: Wall studs must be spaced a minimum of 16" o.c., (See Diagram A).** Mark inside edges of studs the AireShare™ will be installed between and verify there is at least 14" between the inside edges. Slide a stud finder down the wall between the studs to help verify the stud wall cavity is completely open, (See Diagram B).

TOOLS REQUIRED

Hand Sheetrock Saw Phillips & Straight Screwdrivers Level Tape Measure Utility Knife or Scissors Wire Stripper

INSTALLING DISCHARGE DIFFUSER

WARNING: Disrupt power at circuit breaker to outlets and switches within the stud wall you will be working. When sawing through sheetrock you must stop if you detect the saw blade coming in contact with any wiring or plumbing. Investigate further to determine if it is possible to safely continue to use this wall cavity space. Switch to another stud wall cavity if necessary.

NOTE: Typical installations will have the Diffuser high and the Blower low, but there may be instances where it is desirable to have the Blower mounted high and the Diffuser low to take air from the ceiling level.

IMPORTANT: Install Diffuser first if mounting the Blower down low and the Diffuser high so sheetrock from the Diffuser cut out does not fall into wall cavity and damage Blower. Install the Blower first if mounting the Blower high and Diffuser low so sheetrock from the Blower cut out does not fall into wall cavity and damage Diffuser.

1. Determine if you would like a high or low discharge. The Diffuser may be mounted as close as 3" above the top of Blower cut out opening or as close as 3" to the ceiling.
2. Level and mark a line between studs where you want the top of the Diffuser, (See Diagram C)
3. Using a hand sheetrock saw carefully make a horizontal cut along the line. Cut the sheetrock completely until you come in contact with the opposite stud. **NOTE:** If studs are spaced greater than 16" o.c., the horizontal cut line should not exceed 13 5/8", (See Diagram D).





DIAGRAM C



DIAGRAM D



- Cut out Diffuser template on dashed lines. Align the top of template with the wall cut and center it so that there is an equal space between the right and left edges of the template and ends of the cut in the sheetrock. Mark all 4 corners of template, connect with a straight edge and cut Diffuser opening in wall (**Diffuser opening should be 1 1/4" high x 13 5/8" wide**), (See Diagram E).
- Insert Diffuser with the air scoop on the back pointing towards the Blower. Adjust tangs on the sides if necessary to secure a tight fit into the wall opening, (See Diagram F).

DIAGRAM E



CENTER DIFFUSER TEMPLATE ALONG SHEETROCK CUT AND MARK 4 CORNERS. CUT OUT DIFFUSER OPENING. (1 1/4" HIGH x 13 5/8" WIDE)

DIAGRAM F



INSERT DIFFUSER INTO WALL WITH AIR SCOOP POINTING TOWARDS BLOWER.

BLOWER INSTALLATION

WARNING: Disrupt power at circuit breaker to outlets and switches within the stud wall you will be working. When sawing through sheetrock you must stop if you detect the saw blade coming in contact with any wiring or plumbing. Investigate further to determine if it is possible to safely continue to use this wall cavity space. Switch to another stud wall cavity if necessary.

NOTE: Typical installations will have the Diffuser high and the Blower low, but there may be instances where it is desirable to have the Blower mounted high and the Diffuser low to take air from the ceiling level.

IMPORTANT: Install Diffuser first if mounting the Blower down low and the Diffuser high so sheetrock from the Diffuser cut out does not fall into wall cavity and damage Blower. Install the Blower first if mounting the Blower high and Diffuser low so sheetrock from the Blower cut out does not fall into wall cavity and damage Diffuser.

- Using a stud finder mark the center of the stud on each side of the wall cavity that the AS2 Blower and Intake Grille will be installed, (See Diagram G). These instructions assume standard 16" on center studs.
- Position the AS2 Intake Grille at the desired height on the wall, centered between the two 16" on center studs. Level and lightly mark the grille position through the two mounting holes. **IMPORTANT:** Make sure Intake Grille flanges do not interfere with baseboards & outlets. If Intake Grille is mounted up high towards the ceiling, the top flange must be mounted 1" below the ceiling so Intake Grille top opening clears double plate at top of stud walls, (See Diagram H).
- Mark a level line 3 5/8" straight above and below each Intake Grille mounting hole and connect the tops and bottoms horizontally with a Level, (See Diagram I).

DIAGRAM G




USE STUD FINDER TO DETERMINE CENTER OF STUDS IN CAVITY.

DIAGRAM H



POSITION INTAKE GRILLE AT DESIRED HEIGHT, LEVEL & MARK MOUNTING HOLES ON STUDS.

DIAGRAM I



MARK A LEVEL LINE 3 5/8" STRAIGHT ABOVE AND BELOW GRILLE CENTER HOLES. LEVEL TOPS & BOTTOMS OF LINES ACROSS.

- Starting in the center of each line cut the dry wall using a hand saw until contact is made with one of the studs. Reverse the saw and cut along the line in the opposite direction until contact is made with the opposite stud. Cut vertically along each stud to connect the horizontal cuts and remove the dry wall (**AS2 Blower opening should be 7 1/4" high x 14 1/2" wide**), (See Diagram J).
- Provide a switched 120 VAC power source with leads long enough to connect to the motor leads of the AireShare™ while it is positioned just outside Blower opening cut in sheetrock, (See Diagram K).
- Carefully insert the Blower into the cutout. Level the top flange and mark the larger Blower flange mounting holes. Using the provided wood screws, secure the blower to the wall studs. Wire to AS2 using provided strain relief bushing, (See Diagram L).

DIAGRAM J



CAREFULLY CUT BLOWER OPENING IN SHEETROCK ALONG HORIZONTAL LINES AND CONNECT ENDS VERTICALLY.

DIAGRAM K



PROVIDE SWITCHED 120 VAC POWER SOURCE LEAD FOR BLOWER.

DIAGRAM L



SECURE BLOWER TO WALL AND CONNECT 120 VAC POWER SOURCE TO BLOWER MOTOR LEADS.

8. Secure J-box cover to Blower electrical box once wiring is complete, (See Diagram M).

9. Attach Intake Grille to wall with provided screws, (See Diagram N).

DIAGRAM M



ATTACH J-BOX COVER TO BLOWER J-BOX.

DIAGRAM N



ATTACH GRILLE TO WALL WITH PROVIDED SCREWS.

WIRING


WARNING

Disrupt power at circuit breaker to outlets and switches within the stud wall you will be working.

The AS2 blower is factory wired with a 2.5 μF capacitor wired to the brown motor lead. The blower will run at high speed when no additional capacitors are installed. Wire the included 6 μF capacitor in series with the Black (L1) motor lead for medium speed. Wire the included 5 μF capacitor in series with the Black (L1) motor lead for low speed. In both cases leave the 2.5 μF capacitor wired to the brown motor lead.

If wiring into a switched 120 VAC power source follow the AS2 connection diagram below. If using the optional FC24 Fan Center to control the Aireshare by a 24 volt thermostat follow the FC24 wiring diagrams.


AIRESHARE™ MODEL AS2 WIRING CONNECTIONS




AS2 SPEED OPTIONS



OR




OR



NOTE: A 2.5 μF CAPACITOR IS ALWAYS USED ON THE 120 VAC "N" LEAD, AND IS WIRED BETWEEN THE WHITE AND BROWN LEADS OF THE MOTOR.


AIRESHARE™ MODEL AS2 WIRING CONNECTIONS WITH THE OPTIONAL FC24 FAN CENTER




AS2 SPEED OPTIONS



OR




OR




NOTE: A 2.5 μ F CAPACITOR IS ALWAYS USED ON THE 120 VAC "N" LEAD, AND IS WIRED BETWEEN THE WHITE AND BROWN LEADS OF THE MOTOR.

OPTIONAL FC24 FAN CENTER T-STAT WIRING CONNECTIONS

24 VAC WALL T-STAT WITH NO "C" TERMINAL



24 VAC WALL T-STAT WITH "C" TERMINAL



- * (FAN ON) G = FAN RUNS CONSTANTLY.
- (HEAT) W = FAN RUNS ON TEMPERATURE FALL.
- (COOL) Y = FAN RUNS ON TEMPERATURE RISE.

8089031 9/4/14

MAINTENANCE

The AireShare™ Blower wheel should be inspected annually and carefully cleaned or vacuumed with a bristle brush head if necessary. The motor is permanently lubricated and requires no maintenance.

ACCESSORY CONTROLS

- FC24 24V Fan Center to interface any 24V Thermostat (Allows control on temperature rise & fall with 24V thermostat)
- SWT Switch-It™ Wireless Digital Thermostat (Heat Only Applications - Activates on temperature fall)
- SWS Switch-It™ Wireless Wall Switch
- DK2 AS2 Duct Kit for installation in obstructed wall cavities, where metal studs with wiring knock outs are used or to conform to energy codes requiring metal ducts.

REPLACEMENT PARTS AND WARRANTY

<u>Component</u>	<u>Part Number</u>	<u>Component</u>	<u>Part Number</u>
AS2 Intake Grille	950-3320	AS2 Blower Assembly	950-3319
AS1, AS2 Diffuser	950-3302	AS2 Motor Capacitor Kit	950-3321

TJERNLUND LIMITED ONE YEAR WARRANTY

Tjernlund Products, Inc. warrants to the original purchaser of this product that the product will be free from defects due to faulty material or workmanship for a period of (1) year from the date of original purchase or delivery to the original purchaser, whichever is earlier. Remedies under this warranty are limited to repairing or replacing, at our option, any product which shall, within the above stated warranty period, be returned to Tjernlund Products, Inc. at the address listed below, postage prepaid. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, AND TJERNLUND PRODUCTS, INC. EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF THIS PRODUCT. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES AND NO AGENT IS AUTHORIZED TO ASSUME FOR US ANY LIABILITY ADDITIONAL TO THOSE SET FORTH IN THIS LIMITED WARRANTY. IMPLIED WARRANTIES ARE LIMITED TO THE STATED DURATION OF THIS LIMITED WARRANTY. Some states do not allow limitation on how long an implied warranty lasts, so that limitation may not apply to you. In addition, some states do not allow the exclusion or limitation of incidental or consequential damages, so that above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from State to State. Send all inquiries regarding warranty work to Tjernlund Products, Inc. 1601 9th Street, White Bear Lake, MN 55110-6794. Phone (651) 426-2993 • (800) 255-4208 • Fax (651) 426-9547 • Email fanmail@tjfans.com.