

CZRD-XX Round, CZRD-XXXX Side and Bottom Mount Rectangular Weight Chart

Use this chart as a reference when adjusting for vertical up-flow applications.

FOR 1.5" DIAMETER WEIGHTS

CZRD-XX Round	# of Weights for Horizontal Air Flow	# of Weights for Vertical Up-Flow
CZRD-06	2	1
CZRD-07	2	2
CZRD-08	6	3
CZRD-09	7	2
CZRD-10	8	4
CZRD-12	15	4
CZRD-14	24	5
CZRD-16	24	16
CZRD-18	40	20

CZRD-XXXX Side and Bottom Mount	# of Weights for Horizontal Air Flow	# of Weights for Vertical Up-Flow	CZRD-XXXX Side and Bottom Mount	# of Weights for Horizontal Air Flow	# of Weights for Vertical Up-Flow
CZRD-0808	4	2	CZRD-2008	12	3
CZRD-1008	5	3	CZRD-2010	24	6
CZRD-1010	9	3	CZRD-2012	30	6
CZRD-1208	6	3	CZRD-2014	40	10
CZRD-1210	12	5	CZRD-2016	45	12
CZRD-1212	14	4	CZRD-2208	15	3
CZRD-1408	6	3	CZRD-2210	24	7
CZRD-1410	20	3	CZRD-2212	40	8
CZRD-1412	27	6	CZRD-2214	40	12
CZRD-1414	36	6	CZRD-2408	15	6
CZRD-1608	9	3	CZRD-2410	23	6
CZRD-1610	11	3	CZRD-2412	40	8
CZRD-1612	30	6	CZRD-2414	50	14
CZRD-1614	27	6	CZRD-2608	15	3
CZRD-1616	50	15	CZRD-2610	27	12
CZRD-1808	12	3	CZRD-2612	50	12
CZRD-1810	15	4	CZRD-3008	42	10
CZRD-1812	27	6	CZRD-3010	46	12
CZRD-1814	40	8	CZRD-3012	72	25



1985 Carroll Street, Clearwater, FL 33765 -- (727) 431-6197
www.fahrenheitseries.com