

# Ultravation®

Professional Indoor Air Quality Products

## UVP-6000 Portable Air Cleaning System



**Model Number: 92-163**  
**Table of Contents:**

Page 2 – Introduction, Applications, Maintenance

Page 2 – Warranty

**Read Before Use**

## Introduction and Application:

This Ultravation Portable Photocatalytic and Germicidal UVC Air Cleaning System is designed to remove dirt, dust, pollen, and microscopic particles: reduce unpleasant odors, VOC gases and the microbial population from the air that circulates through it.

Step 1: Trapping particles in the washable filter.

Step 2: VOC's and gases such as the fumes from new carpets, paints, nail polish, cigar and cigarette smoke are drastically reduced photo chemically via a process known as photo catalytic conversion or photo catalytic oxidation.

Step 3: Germicidal UVC light is applied to the Air to drastically reduce unwanted Viruses and Bacteria

The Ultravation Portable Air Cleaning System is great for use in your office; on a night stand; or next to the couch on an end table. The size makes it very easy to relocate between home and office.

## Safety Precautions:

**WARNING: UV Hazard. Always protect eyes from ultraviolet light. NEVER look at UV lamps in operation. Do no disassemble unit and operate.**

## Replacement Parts:

Filter + Filter Guard:	<b>91-042</b>
4" UVC Advanced Oxidation Lamp:	<b>LP-PP-0095</b>

## Maintenance:

Replace lamp and annually. The filter media in your air cleaner must be cleaned periodically. The frequency of filter cleaning is best determined by visual examination. However, an annual cleaning of the filter is strongly recommended.

### Steps for cleaning filter:

1. Unplug unit.
2. Open the filter guard by pulling on a corner.
3. Remove Filter.
4. Rinse filters out with normal tap water.
5. Let filter dry for minimum 15 minutes before replacing them into the unit.
6. Replace filters and snap on filter guards.

### Lamp replacement:

1. Unplug unit and remove cover by removing 2 phillips head screws from bottom of unit.
2. Remove existing lamp removing it from the clips. Unplug lamp from power supply housing by pulling connector straight off.
3. Install new lamp by plugging it into the lamp connector and clipping it back into the clips.
4. Replace cover and secure with screws.

## Warranty:

Ultravation warrants this product against any defects in material or workmanship for a period of 3 years after date of purchase. This warranty does not include damage to the unit from accident, misuse or improper installation. If this product should become defective during the warranty period, Ultravation will elect to repair or replace the product free of charge. Ultravation will return repaired or replaced warranted products pre-paid, provided that the product was delivered pre-paid. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. All returns must be accompanied by a return authorization number, which may be obtained by contacting Ultravation, Inc...

Ultravation, Inc. ~ P.O. Box 165 ~ 212 Ideal Way ~ Poultney, Vermont 05764  
Phone: 866-468-8247 ~ Fax: 802-287-9203~ [www.ultravation.com](http://www.ultravation.com)